WORK INSTRUCTION

Document ID: DOC-0002330
Project: PRJ-016
Uploaded on: 2025-11-18
Uploaded by: user126
Export class: EAR99

Assembly of P-103729 at plant PLT04

Part Number: P-103729
Revision: A.1
Plant: PLT04
Station: ST-93
Torque (Nm): 12
Cycle time (s): 227

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Record result

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Record result

Step 7: Move to next station

Step 8: Apply thread locker

Assembly of P-103759 at plant PLT03

Part Number: P-103759
Revision: A.1
Plant: PLT03
Station: ST-92
Torque (Nm): 8
Cycle time (s): 148

Step 1: Apply thread locker

Step 2: Record result

Step 3: Torque to specification

Step 4: Record result

Step 5: Move to next station

Step 6: Visual check

Step 7: Inspect incoming part

Assembly of P-101695 at plant PLT03

Part Number: P-101695
Revision: A.1
Plant: PLT03
Station: ST-19

Torque (Nm):	8
Cycle time (s):	137

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Record result