WORK INSTRUCTION

Document ID: DOC-0001418
Project: PRJ-006
Uploaded on: 2024-09-13
Uploaded by: user071
Export class: EAR99

Assembly of P-101941 at plant PLT03

Part Number: P-101941
Revision: A.1
Plant: PLT03
Station: ST-57
Torque (Nm): 20
Cycle time (s): 60

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Clean mating surface

Assembly of P-101297 at plant PLT01

Part Number: P-101297
Revision: A.1
Plant: PLT01
Station: ST-36
Torque (Nm): 8
Cycle time (s): 167

Step 1: Visual check

Step 2: Move to next station

Step 3: Visual check

Step 4: Record result

Step 5: Torque to specification

Step 6: Torque to specification

Step 7: Record result

Assembly of P-100977 at plant PLT02

Part Number: P-100977
Revision: A.1
Plant: PLT02
Station: ST-52
Torque (Nm): 8
Cycle time (s): 164

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Inspect incoming part