WORK INSTRUCTION

Document ID: DOC-0001425
Project: PRJ-009
Uploaded on: 2024-09-16
Uploaded by: user125
Export class: EAR99

Assembly of P-100540 at plant PLT02

Part Number: P-100540
Revision: A.1
Plant: PLT02
Station: ST-89
Torque (Nm): 8
Cycle time (s): 110

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Inspect incoming part

Assembly of P-101383 at plant PLT04

Part Number: P-101383
Revision: A.1
Plant: PLT04
Station: ST-44
Torque (Nm): 20
Cycle time (s): 150

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Clean mating surface

Assembly of P-101358 at plant PLT02

Part Number: P-101358
Revision: A.1
Plant: PLT02
Station: ST-77
Torque (Nm): 2.5
Cycle time (s): 187

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Fit fasteners