EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000007
Project: PRJ-031
Uploaded on: 2022-11-07
Uploaded by: user103
Export class: ECCN-3A001

Assembly of P-100016 at plant PLT01

Part Number: P-100016
Revision: A.1
Plant: PLT01
Station: ST-29
Torque (Nm): 20
Cycle time (s): 30

Step 1: Clean mating surface

Step 2: Record result

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Record result

Step 7: Visual check

Assembly of P-100008 at plant PLT01

Part Number: P-100008
Revision: A.1
Plant: PLT01
Station: ST-27
Torque (Nm): 12
Cycle time (s): 255

Step 1: Clean mating surface

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Torque to specification