WORK INSTRUCTION

Document ID: DOC-0000010
Project: PRJ-013
Uploaded on: 2022-11-09
Uploaded by: user105
Export class: EAR99

Assembly of P-100001 at plant PLT01

Part Number: P-100001
Revision: A.1
Plant: PLT01
Station: ST-23
Torque (Nm): 5
Cycle time (s): 48

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Visual check

Assembly of P-100002 at plant PLT03

Part Number: P-100002
Revision: A.1
Plant: PLT03
Station: ST-10
Torque (Nm): 8
Cycle time (s): 67

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Record result

Step 6: Clean mating surface

Step 7: Move to next station

Step 8: Visual check

Assembly of P-100022 at plant PLT03

Part Number: P-100022
Revision: A.1
Plant: PLT03

Station:	ST-79
Torque (Nm):	12
Cycle time (s):	278

Step 1: Visual check

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Move to next station

Step 7: Torque to specification

Step 8: Visual check