WORK INSTRUCTION

Document ID: DOC-0000013
Project: PRJ-019
Uploaded on: 2022-11-10
Uploaded by: user196
Export class: EAR99

Assembly of P-100020 at plant PLT03

Part Number: P-100020
Revision: A.1
Plant: PLT03
Station: ST-12
Torque (Nm): 8
Cycle time (s): 194

Step 1: Record result

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Apply thread locker

Step 7: Torque to specification

Assembly of P-100022 at plant PLT03

Part Number: P-100022
Revision: A.1
Plant: PLT03
Station: ST-86
Torque (Nm): 12
Cycle time (s): 114

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Move to next station

Assembly of P-100018 at plant PLT02

Part Number: P-100018
Revision: A.1
Plant: PLT02
Station: ST-75
Torque (Nm): 5
Cycle time (s): 218

Step 1: Record result

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Visual check

Step 6: Clean mating surface