WORK INSTRUCTION

Document ID: DOC-0000032
Project: PRJ-027
Uploaded on: 2022-11-19
Uploaded by: user107
Export class: EAR99

Assembly of P-100010 at plant PLT04

Part Number: P-100010
Revision: A.1
Plant: PLT04
Station: ST-37
Torque (Nm): 2.5
Cycle time (s): 237

Step 1: Apply thread locker

Step 2: Record result

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Move to next station

Step 6: Move to next station

Assembly of P-100005 at plant PLT01

Part Number: P-100005
Revision: A.1
Plant: PLT01
Station: ST-47
Torque (Nm): 12
Cycle time (s): 274

Step 1: Visual check

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Apply thread locker

Step 6: Move to next station

Assembly of P-100055 at plant PLT01

Part Number: P-100055
Revision: A.1
Plant: PLT01
Station: ST-51
Torque (Nm): 12
Cycle time (s): 254

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Apply thread locker