WORK INSTRUCTION

Document ID: DOC-0000040
Project: PRJ-015
Uploaded on: 2022-11-22
Uploaded by: user104
Export class: EAR99

Assembly of P-100016 at plant PLT01

Part Number: P-100016
Revision: A.1
Plant: PLT01
Station: ST-54
Torque (Nm): 20
Cycle time (s): 161

Step 1: Clean mating surface

Step 2: Record result

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Inspect incoming part

Assembly of P-100017 at plant PLT02

Part Number: P-100017
Revision: A.1
Plant: PLT02
Station: ST-65
Torque (Nm): 12
Cycle time (s): 134

Step 1: Record result

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Inspect incoming part

Assembly of P-100007 at plant PLT01

Part Number: P-100007
Revision: A.1
Plant: PLT01
Station: ST-36
Torque (Nm): 12
Cycle time (s): 218

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Visual check

Step 5: Move to next station

Step 6: Apply thread locker

Step 7: Move to next station

Step 8: Visual check