EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000047
Project: PRJ-036
Uploaded on: 2022-11-24
Uploaded by: user126
Export class: ECCN-3A001

Assembly of P-100028 at plant PLT03

Part Number: P-100028
Revision: A.1
Plant: PLT03
Station: ST-63
Torque (Nm): 8
Cycle time (s): 283

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Record result

Step 7: Inspect incoming part

Assembly of P-100051 at plant PLT03

Part Number: P-100051
Revision: A.1
Plant: PLT03
Station: ST-99
Torque (Nm): 5
Cycle time (s): 191

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Record result

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Apply thread locker

Step 7: Move to next station

Step 8: Inspect incoming part