EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000064
Project: PRJ-034
Uploaded on: 2022-12-03
Uploaded by: user093
Export class: ECCN-3A001

Assembly of P-100039 at plant PLT02

Part Number: P-100039
Revision: A.1
Plant: PLT02
Station: ST-43
Torque (Nm): 5
Cycle time (s): 74

Step 1: Apply thread locker

Step 2: Record result

Step 3: Torque to specification

Step 4: Record result

Step 5: Apply thread locker

Assembly of P-100065 at plant PLT02

Part Number: P-100065
Revision: A.1
Plant: PLT02
Station: ST-26
Torque (Nm): 20
Cycle time (s): 277

Step 1: Torque to specification

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Apply thread locker

Assembly of P-100008 at plant PLT01

Part Number: P-100008
Revision: A.1
Plant: PLT01
Station: ST-26
Torque (Nm): 20
Cycle time (s): 260

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Visual check

Step 7: Record result

Step 8: Visual check