WORK INSTRUCTION

Document ID: DOC-0000067
Project: PRJ-025
Uploaded on: 2022-12-05
Uploaded by: user182
Export class: EAR99

Assembly of P-100114 at plant PLT01

Part Number: P-100114
Revision: A.1
Plant: PLT01
Station: ST-30
Torque (Nm): 5
Cycle time (s): 90

Step 1: Move to next station

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Record result

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Move to next station

Assembly of P-100047 at plant PLT04

Part Number: P-100047
Revision: A.1
Plant: PLT04
Station: ST-56
Torque (Nm): 2.5
Cycle time (s): 33

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Inspect incoming part

Step 6: Apply thread locker

Step 7: Clean mating surface

Step 8: Torque to specification

Assembly of P-100073 at plant PLT02

Part Number: P-100073
Revision: A.1
Plant: PLT02
Station: ST-64

Torque (Nm): 5
Cycle time (s): 283

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Inspect incoming part

Step 7: Clean mating surface

Step 8: Record result