EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000069
Project: PRJ-010
Uploaded on: 2022-12-06
Uploaded by: user137
Export class: ECCN-3A001

Assembly of P-100100 at plant PLT04

Part Number: P-100100
Revision: A.1
Plant: PLT04
Station: ST-25
Torque (Nm): 12
Cycle time (s): 273

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Visual check

Step 5: Record result

Step 6: Torque to specification

Step 7: Inspect incoming part

Step 8: Fit fasteners

Assembly of P-100026 at plant PLT01

Part Number: P-100026
Revision: A.1
Plant: PLT01
Station: ST-54
Torque (Nm): 20
Cycle time (s): 242

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Record result

Step 4: Fit fasteners

Step 5: Clean mating surface