WORK INSTRUCTION

Document ID: DOC-0000074
Project: PRJ-032
Uploaded on: 2022-12-08
Uploaded by: user048
Export class: EAR99

Assembly of P-100071 at plant PLT04

Part Number: P-100071
Revision: A.1
Plant: PLT04
Station: ST-32
Torque (Nm): 2.5
Cycle time (s): 53

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Torque to specification

Step 8: Apply thread locker

Assembly of P-100010 at plant PLT04

Part Number: P-100010
Revision: A.1
Plant: PLT04
Station: ST-55
Torque (Nm): 8
Cycle time (s): 148

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Move to next station

Step 7: Clean mating surface

Step 8: Clean mating surface