WORK INSTRUCTION

Document ID: DOC-0000114
Project: PRJ-008
Uploaded on: 2022-12-28
Uploaded by: user094
Export class: EAR99

Assembly of P-100088 at plant PLT04

Part Number: P-100088
Revision: A.1
Plant: PLT04
Station: ST-83
Torque (Nm): 2.5
Cycle time (s): 220

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Record result

Assembly of P-100174 at plant PLT03

Part Number: P-100174
Revision: A.1
Plant: PLT03
Station: ST-39
Torque (Nm): 2.5
Cycle time (s): 59

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Record result

Step 6: Inspect incoming part

Assembly of P-100121 at plant PLT02

Part Number: P-100121
Revision: A.1
Plant: PLT02
Station: ST-36
Torque (Nm): 20
Cycle time (s): 226

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Torque to specification