EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000122
Project: PRJ-009
Uploaded on: 2023-01-02
Uploaded by: user087
Export class: ECCN-3A001

Assembly of P-100038 at plant PLT01

Part Number: P-100038
Revision: A.1
Plant: PLT01
Station: ST-81
Torque (Nm): 2.5
Cycle time (s): 47

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Move to next station

Assembly of P-100041 at plant PLT04

Part Number: P-100041
Revision: A.1
Plant: PLT04
Station: ST-21
Torque (Nm): 5
Cycle time (s): 106

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Record result

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Apply thread locker

Assembly of P-100028 at plant PLT03

Part Number: P-100028
Revision: A.1
Plant: PLT03
Station: ST-69
Torque (Nm): 8

Cycle time (s): 61

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Visual check