EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000125
Project: PRJ-013
Uploaded on: 2023-01-04
Uploaded by: user130
Export class: ECCN-3A001

Assembly of P-100061 at plant PLT01

Part Number: P-100061
Revision: A.1
Plant: PLT01
Station: ST-61
Torque (Nm): 20
Cycle time (s): 91

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Inspect incoming part

Assembly of P-100045 at plant PLT02

Part Number: P-100045
Revision: A.1
Plant: PLT02
Station: ST-78
Torque (Nm): 20
Cycle time (s): 292

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Visual check

Step 4: Visual check

Step 5: Visual check