WORK INSTRUCTION

Document ID: DOC-0000129
Project: PRJ-005
Uploaded on: 2023-01-06
Uploaded by: user167
Export class: EAR99

Assembly of P-100208 at plant PLT02

Part Number: P-100208
Revision: A.1
Plant: PLT02
Station: ST-10
Torque (Nm): 20
Cycle time (s): 148

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Record result

Step 4: Move to next station

Step 5: Apply thread locker

Assembly of P-100042 at plant PLT03

Part Number: P-100042
Revision: A.1
Plant: PLT03
Station: ST-13
Torque (Nm): 12
Cycle time (s): 186

Step 1: Visual check

Step 2: Record result

Step 3: Apply thread locker

Step 4: Record result

Step 5: Visual check

Assembly of P-100166 at plant PLT04

Part Number: P-100166
Revision: A.1
Plant: PLT04
Station: ST-58
Torque (Nm): 2.5
Cycle time (s): 174

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Move to next station