EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000134
Project: PRJ-023
Uploaded on: 2023-01-07
Uploaded by: user151
Export class: ECCN-3A001

Assembly of P-100062 at plant PLT03

Part Number: P-100062
Revision: A.1
Plant: PLT03
Station: ST-77
Torque (Nm): 20
Cycle time (s): 290

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Move to next station

Step 7: Torque to specification

Assembly of P-100015 at plant PLT03

Part Number: P-100015
Revision: A.1
Plant: PLT03
Station: ST-16
Torque (Nm): 20
Cycle time (s): 180

Step 1: Torque to specification

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Inspect incoming part

Assembly of P-100036 at plant PLT02

Part Number: P-100036
Revision: A.1
Plant: PLT02
Station: ST-74
Torque (Nm): 12

Cycle time (s): 249

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Inspect incoming part