WORK INSTRUCTION

Document ID: DOC-0000158
Project: PRJ-006
Uploaded on: 2023-01-17
Uploaded by: user034
Export class: EAR99

Assembly of P-100148 at plant PLT02

Part Number: P-100148
Revision: A.1
Plant: PLT02
Station: ST-70
Torque (Nm): 20
Cycle time (s): 235

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Clean mating surface

Assembly of P-100127 at plant PLT01

Part Number: P-100127
Revision: A.1
Plant: PLT01
Station: ST-84
Torque (Nm): 8
Cycle time (s): 250

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Move to next station

Step 5: Inspect incoming part

Assembly of P-100103 at plant PLT03

Part Number: P-100103
Revision: A.1
Plant: PLT03
Station: ST-74
Torque (Nm): 8
Cycle time (s): 166

Step 1: Record result

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Move to next station

Step 7: Apply thread locker