WORK INSTRUCTION

Document ID: DOC-0000210
Project: PRJ-035
Uploaded on: 2023-02-15
Uploaded by: user114
Export class: EAR99

Assembly of P-100105 at plant PLT03

Part Number: P-100105
Revision: A.1
Plant: PLT03
Station: ST-69
Torque (Nm): 8
Cycle time (s): 75

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Clean mating surface

Step 5: Visual check

Step 6: Torque to specification

Step 7: Torque to specification

Assembly of P-100027 at plant PLT03

Part Number: P-100027
Revision: C.1
Plant: PLT03
Station: ST-68
Torque (Nm): 2.5
Cycle time (s): 289

Step 1: Torque to specification

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Inspect incoming part

Assembly of P-100226 at plant PLT04

Part Number: P-100226
Revision: A.1
Plant: PLT04
Station: ST-59
Torque (Nm): 12
Cycle time (s): 112

Step 1: Torque to specification

Step 2: Record result

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Torque to specification