EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000469
Project: PRJ-018
Uploaded on: 2023-06-13
Uploaded by: user191
Export class: ECCN-3A001

Assembly of P-100029 at plant PLT02

Part Number: P-100029
Revision: C.1
Plant: PLT02
Station: ST-73
Torque (Nm): 20
Cycle time (s): 242

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Record result

Step 4: Record result

Step 5: Fit fasteners

Assembly of P-100342 at plant PLT04

Part Number: P-100342
Revision: B.1
Plant: PLT04
Station: ST-94
Torque (Nm): 8
Cycle time (s): 59

Step 1: Visual check

Step 2: Torque to specification

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Apply thread locker

Step 6: Inspect incoming part

Assembly of P-100077 at plant PLT03

Part Number: P-100077
Revision: A.1
Plant: PLT03
Station: ST-28
Torque (Nm): 5
Cycle time (s): 147

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Fit fasteners

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Step 8: Torque to specification