WORK INSTRUCTION

Document ID: DOC-0000851
Project: PRJ-012
Uploaded on: 2023-12-16
Uploaded by: user186
Export class: EAR99

Assembly of P-100543 at plant PLT02

Part Number: P-100543
Revision: A.1
Plant: PLT02
Station: ST-76
Torque (Nm): 12
Cycle time (s): 121

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Fit fasteners

Step 6: Visual check

Assembly of P-101029 at plant PLT03

Part Number: P-101029
Revision: A.1
Plant: PLT03
Station: ST-60
Torque (Nm): 8
Cycle time (s): 239

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Record result

Step 7: Clean mating surface

Step 8: Inspect incoming part