WORK INSTRUCTION

Document ID: DOC-0000872
Project: PRJ-032
Uploaded on: 2023-12-31
Uploaded by: user090
Export class: EAR99

Assembly of P-100314 at plant PLT03

Part Number: P-100314
Revision: A.1
Plant: PLT03
Station: ST-13
Torque (Nm): 8
Cycle time (s): 177

Step 1: Clean mating surface

Step 2: Visual check

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Fit fasteners

Step 7: Torque to specification

Assembly of P-101295 at plant PLT03

Part Number: P-101295
Revision: A.1
Plant: PLT03
Station: ST-65
Torque (Nm): 8
Cycle time (s): 225

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Visual check

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Clean mating surface