WORK INSTRUCTION

Document ID: DOC-0000896
Project: PRJ-007
Uploaded on: 2024-01-19
Uploaded by: user034
Export class: EAR99

Assembly of P-100675 at plant PLT01

Part Number: P-100675
Revision: A.1
Plant: PLT01
Station: ST-16
Torque (Nm): 8
Cycle time (s): 40

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Torque to specification

Step 6: Inspect incoming part

Step 7: Fit fasteners

Assembly of P-100686 at plant PLT03

Part Number: P-100686
Revision: A.1
Plant: PLT03
Station: ST-40
Torque (Nm): 2.5
Cycle time (s): 144

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Clean mating surface

Assembly of P-100457 at plant PLT04

Part Number: P-100457
Revision: A.1
Plant: PLT04
Station: ST-34
Torque (Nm): 8

Cycle time (s): 120

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Record result