WORK INSTRUCTION

Document ID: DOC-0000972
Project: PRJ-022
Uploaded on: 2024-02-21
Uploaded by: user134
Export class: EAR99

Assembly of P-101599 at plant PLT03

Part Number: P-101599
Revision: A.1
Plant: PLT03
Station: ST-42
Torque (Nm): 5
Cycle time (s): 173

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Torque to specification

Assembly of P-100216 at plant PLT03

Part Number: P-100216
Revision: B.1
Plant: PLT03
Station: ST-94
Torque (Nm): 5
Cycle time (s): 57

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Visual check