WORK INSTRUCTION

Document ID: DOC-0001007
Project: PRJ-036
Uploaded on: 2024-03-09
Uploaded by: user051
Export class: EAR99

Assembly of P-101620 at plant PLT03

Part Number: P-101620
Revision: A.1
Plant: PLT03
Station: ST-94
Torque (Nm): 8
Cycle time (s): 72

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Record result

Step 7: Inspect incoming part

Step 8: Record result

Assembly of P-100999 at plant PLT04

Part Number: P-100999
Revision: A.1
Plant: PLT04
Station: ST-31
Torque (Nm): 12
Cycle time (s): 238

Step 1: Fit fasteners

Step 2: Record result

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Inspect incoming part

Assembly of P-100775 at plant PLT02

Part Number: P-100775
Revision: A.1
Plant: PLT02
Station: ST-20
Torque (Nm): 20

Cycle time (s): 187

Step 1: Move to next station

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Move to next station