WORK INSTRUCTION

Document ID: DOC-0001021
Project: PRJ-007
Uploaded on: 2024-03-16
Uploaded by: user108
Export class: EAR99

Assembly of P-101103 at plant PLT01

Part Number: P-101103
Revision: A.1
Plant: PLT01
Station: ST-97
Torque (Nm): 20
Cycle time (s): 47

Step 1: Torque to specification

Step 2: Visual check

Step 3: Record result

Step 4: Fit fasteners

Step 5: Move to next station

Step 6: Visual check

Step 7: Torque to specification

Assembly of P-101521 at plant PLT03

Part Number: P-101521
Revision: A.1
Plant: PLT03
Station: ST-82
Torque (Nm): 20
Cycle time (s): 247

Step 1: Visual check

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Visual check

Assembly of P-100244 at plant PLT03

Part Number: P-100244
Revision: B.1
Plant: PLT03
Station: ST-98

Torque (Nm):	8
Cycle time (s):	138

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Torque to specification

Step 7: Move to next station

Step 8: Torque to specification