WORK INSTRUCTION

Document ID: DOC-0001030
Project: PRJ-030
Uploaded on: 2024-03-23
Uploaded by: user014
Export class: EAR99

Assembly of P-101450 at plant PLT04

Part Number: P-101450
Revision: A.1
Plant: PLT04
Station: ST-56
Torque (Nm): 2.5
Cycle time (s): 31

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Inspect incoming part

Step 8: Apply thread locker

Assembly of P-101263 at plant PLT03

Part Number: P-101263
Revision: A.1
Plant: PLT03
Station: ST-98
Torque (Nm): 5
Cycle time (s): 74

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Record result

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-101654 at plant PLT01

Part Number: P-101654
Revision: A.1
Plant: PLT01

Station:	ST-77
Torque (Nm):	8
Cycle time (s):	238

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Torque to specification