WORK INSTRUCTION

Document ID: DOC-0001058
Project: PRJ-006
Uploaded on: 2024-04-09
Uploaded by: user111
Export class: EAR99

Assembly of P-101770 at plant PLT04

Part Number: P-101770
Revision: A.1
Plant: PLT04
Station: ST-89
Torque (Nm): 20
Cycle time (s): 179

Step 1: Move to next station

Step 2: Visual check

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Move to next station

Assembly of P-100458 at plant PLT01

Part Number: P-100458
Revision: A.1
Plant: PLT01
Station: ST-75
Torque (Nm): 2.5
Cycle time (s): 232

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Record result

Step 5: Fit fasteners

Step 6: Inspect incoming part

Assembly of P-101227 at plant PLT04

Part Number: P-101227
Revision: A.1
Plant: PLT04
Station: ST-28
Torque (Nm): 20
Cycle time (s): 158

Step 1: Move to next station

Step 2: Visual check

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Inspect incoming part