WORK INSTRUCTION

Document ID: DOC-0001171
Project: PRJ-011
Uploaded on: 2024-06-01
Uploaded by: user048
Export class: EAR99

Assembly of P-101707 at plant PLT03

Part Number: P-101707
Revision: A.1
Plant: PLT03
Station: ST-99
Torque (Nm): 8
Cycle time (s): 109

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Record result

Step 4: Visual check

Step 5: Fit fasteners

Assembly of P-100978 at plant PLT04

Part Number: P-100978
Revision: A.1
Plant: PLT04
Station: ST-21
Torque (Nm): 5
Cycle time (s): 134

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Record result

Step 4: Record result

Step 5: Record result

Step 6: Visual check

Assembly of P-100474 at plant PLT02

Part Number: P-100474
Revision: A.1
Plant: PLT02
Station: ST-15
Torque (Nm): 20
Cycle time (s): 46

Step 1: Record result

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Record result

Step 5: Clean mating surface