WORK INSTRUCTION

Document ID: DOC-0001176
Project: PRJ-001
Uploaded on: 2024-06-02
Uploaded by: user164
Export class: EAR99

Assembly of P-101013 at plant PLT03

Part Number: P-101013
Revision: A.1
Plant: PLT03
Station: ST-41
Torque (Nm): 20
Cycle time (s): 122

Step 1: Record result

Step 2: Visual check

Step 3: Clean mating surface

Step 4: Record result

Step 5: Clean mating surface

Step 6: Record result

Step 7: Fit fasteners

Assembly of P-100659 at plant PLT03

Part Number: P-100659
Revision: A.1
Plant: PLT03
Station: ST-68
Torque (Nm): 2.5
Cycle time (s): 291

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Torque to specification