**ITAR CONTROLLED - USML CATEGORY XIX**

# WORK INSTRUCTION

**Document ID:** DOC-0001212
**Project:** PRJ-032
**Uploaded on:** 2024-06-17
**Uploaded by:** user011
**Export class:** ITAR-USML-XIX

## Assembly of P-101327 at plant PLT01

**Part Number:** P-101327
**Revision:** A.1
**Plant:** PLT01
**Station:** ST-11
**Torque (Nm):** 5
**Cycle time (s):** 89

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Move to next station

Step 7: Fit fasteners

Step 8: Torque to specification

## Assembly of P-101074 at plant PLT02

**Part Number:** P-101074
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-99
**Torque (Nm):** 8
**Cycle time (s):** 225

Step 1: Move to next station

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Record result

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Apply thread locker