WORK INSTRUCTION

Document ID: DOC-0001398
Project: PRJ-017
Uploaded on: 2024-09-05
Uploaded by: user158
Export class: EAR99

Assembly of P-100911 at plant PLT01

Part Number: P-100911
Revision: A.1
Plant: PLT01
Station: ST-61
Torque (Nm): 12
Cycle time (s): 78

Step 1: Torque to specification

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Fit fasteners

Step 8: Move to next station

Assembly of P-100247 at plant PLT04

Part Number: P-100247
Revision: B.1
Plant: PLT04
Station: ST-41
Torque (Nm): 20
Cycle time (s): 63

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Record result

Step 7: Apply thread locker