WORK INSTRUCTION

Document ID: DOC-0001405
Project: PRJ-024
Uploaded on: 2024-09-09
Uploaded by: user180
Export class: EAR99

Assembly of P-101341 at plant PLT02

Part Number: P-101341
Revision: A.1
Plant: PLT02
Station: ST-28
Torque (Nm): 8
Cycle time (s): 52

Step 1: Record result

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Record result

Step 6: Torque to specification

Step 7: Move to next station

Assembly of P-100694 at plant PLT01

Part Number: P-100694
Revision: A.1
Plant: PLT01
Station: ST-77
Torque (Nm): 20
Cycle time (s): 133

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Apply thread locker

Step 7: Inspect incoming part

Assembly of P-101428 at plant PLT02

Part Number: P-101428
Revision: B.1
Plant: PLT02
Station: ST-58
Torque (Nm): 8

Cycle time (s): 122

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Clean mating surface

Step 5: Apply thread locker

Step 6: Clean mating surface

Step 7: Fit fasteners

Step 8: Record result