WORK INSTRUCTION

Document ID: DOC-0001457
Project: PRJ-003
Uploaded on: 2024-10-01
Uploaded by: user191
Export class: EAR99

Assembly of P-100030 at plant PLT03

Part Number: P-100030
Revision: A.1
Plant: PLT03
Station: ST-33
Torque (Nm): 12
Cycle time (s): 179

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Record result

Step 6: Apply thread locker

Step 7: Fit fasteners

Assembly of P-101812 at plant PLT02

Part Number: P-101812
Revision: A.1
Plant: PLT02
Station: ST-57
Torque (Nm): 12
Cycle time (s): 38

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Visual check

Assembly of P-101650 at plant PLT02

Part Number: P-101650
Revision: A.1
Plant: PLT02
Station: ST-34
Torque (Nm): 8

Cycle time (s): 198

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Record result

Step 4: Apply thread locker

Step 5: Move to next station