WORK INSTRUCTION

Document ID: DOC-0001461
Project: PRJ-025
Uploaded on: 2024-10-03
Uploaded by: user137
Export class: EAR99

Assembly of P-100365 at plant PLT01

Part Number: P-100365
Revision: A.1
Plant: PLT01
Station: ST-29
Torque (Nm): 20
Cycle time (s): 64

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Visual check

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Inspect incoming part

Step 8: Visual check

Assembly of P-100511 at plant PLT03

Part Number: P-100511
Revision: A.1
Plant: PLT03
Station: ST-14
Torque (Nm): 20
Cycle time (s): 232

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Move to next station