EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001488
Project: PRJ-015
Uploaded on: 2024-10-16
Uploaded by: user111
Export class: ECCN-3A001

Assembly of P-102114 at plant PLT01

Part Number: P-102114
Revision: A.1
Plant: PLT01
Station: ST-28
Torque (Nm): 5
Cycle time (s): 264

Step 1: Clean mating surface

Step 2: Apply thread locker

Step 3: Record result

Step 4: Torque to specification

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-100461 at plant PLT01

Part Number: P-100461
Revision: A.1
Plant: PLT01
Station: ST-42
Torque (Nm): 12
Cycle time (s): 258

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Record result

Step 7: Visual check

Assembly of P-100826 at plant PLT02

Part Number: P-100826
Revision: A.1
Plant: PLT02

Station:	ST-39
Torque (Nm):	5
Cycle time (s):	273

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Torque to specification

Step 4: Inspect incoming part

Step 5: Move to next station

Step 6: Torque to specification

Step 7: Record result