WORK INSTRUCTION

Document ID: DOC-0001498
Project: PRJ-036
Uploaded on: 2024-10-18
Uploaded by: user122
Export class: EAR99

Assembly of P-100571 at plant PLT03

Part Number: P-100571
Revision: A.1
Plant: PLT03
Station: ST-56
Torque (Nm): 8
Cycle time (s): 89

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Fit fasteners

Step 7: Inspect incoming part

Step 8: Apply thread locker

Assembly of P-100275 at plant PLT04

Part Number: P-100275
Revision: B.1
Plant: PLT04
Station: ST-74
Torque (Nm): 5
Cycle time (s): 129

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Record result

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Record result