EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001547
Project: PRJ-019
Uploaded on: 2024-11-10
Uploaded by: user103
Export class: ECCN-3A001

Assembly of P-101639 at plant PLT03

Part Number: P-101639
Revision: A.1
Plant: PLT03
Station: ST-75
Torque (Nm): 12
Cycle time (s): 155

Step 1: Record result

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Visual check

Step 8: Inspect incoming part

Assembly of P-100645 at plant PLT02

Part Number: P-100645
Revision: A.1
Plant: PLT02
Station: ST-81
Torque (Nm): 2.5
Cycle time (s): 127

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Visual check

Step 5: Record result

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Visual check

Assembly of P-101091 at plant PLT03

Part Number: P-101091

Revision:	B.1
Plant:	PLT03
Station:	ST-12
Torque (Nm):	2.5
Cycle time (s):	99

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Torque to specification

Step 4: Torque to specification

Step 5: Visual check