WORK INSTRUCTION

Document ID: DOC-0001563
Project: PRJ-021
Uploaded on: 2024-11-16
Uploaded by: user083
Export class: EAR99

Assembly of P-102278 at plant PLT01

Part Number: P-102278
Revision: A.1
Plant: PLT01
Station: ST-31
Torque (Nm): 2.5
Cycle time (s): 264

Step 1: Move to next station

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Torque to specification

Assembly of P-101113 at plant PLT02

Part Number: P-101113
Revision: A.1
Plant: PLT02
Station: ST-60
Torque (Nm): 8
Cycle time (s): 52

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Torque to specification

Step 6: Visual check

Step 7: Apply thread locker