EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001607
Project: PRJ-016
Uploaded on: 2024-12-07
Uploaded by: user093
Export class: ECCN-3A001

Assembly of P-102170 at plant PLT03

Part Number: P-102170
Revision: A.1
Plant: PLT03
Station: ST-86
Torque (Nm): 8
Cycle time (s): 266

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Record result

Step 6: Fit fasteners

Step 7: Torque to specification

Step 8: Clean mating surface

Assembly of P-101539 at plant PLT04

Part Number: P-101539
Revision: A.1
Plant: PLT04
Station: ST-44
Torque (Nm): 5
Cycle time (s): 183

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Clean mating surface

Step 8: Visual check