WORK INSTRUCTION

Document ID: DOC-0001620
Project: PRJ-030
Uploaded on: 2024-12-15
Uploaded by: user077
Export class: EAR99

Assembly of P-102109 at plant PLT04

Part Number: P-102109
Revision: A.1
Plant: PLT04
Station: ST-58
Torque (Nm): 12
Cycle time (s): 287

Step 1: Clean mating surface

Step 2: Visual check

Step 3: Torque to specification

Step 4: Visual check

Step 5: Move to next station

Step 6: Fit fasteners

Assembly of P-102238 at plant PLT03

Part Number: P-102238
Revision: A.1
Plant: PLT03
Station: ST-18
Torque (Nm): 5
Cycle time (s): 130

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Fit fasteners