WORK INSTRUCTION

Document ID: DOC-0001642
Project: PRJ-019
Uploaded on: 2024-12-26
Uploaded by: user056
Export class: EAR99

Assembly of P-102227 at plant PLT02

Part Number: P-102227
Revision: A.1
Plant: PLT02
Station: ST-34
Torque (Nm): 8
Cycle time (s): 217

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Fit fasteners

Step 7: Record result

Step 8: Record result

Assembly of P-101555 at plant PLT01

Part Number: P-101555
Revision: A.1
Plant: PLT01
Station: ST-85
Torque (Nm): 2.5
Cycle time (s): 115

Step 1: Inspect incoming part

Step 2: Apply thread locker

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Clean mating surface

Step 6: Record result

Step 7: Move to next station

Step 8: Visual check

Assembly of P-102174 at plant PLT03

Part Number: P-102174
Revision: A.1
Plant: PLT03

Station: ST-17
Torque (Nm): 2.5
Cycle time (s): 234

Step 1: Torque to specification

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Visual check

Step 5: Visual check

Step 6: Visual check

Step 7: Inspect incoming part