WORK INSTRUCTION

Document ID: DOC-0001721
Project: PRJ-006
Uploaded on: 2025-02-01
Uploaded by: user092
Export class: EAR99

Assembly of P-100076 at plant PLT01

Part Number: P-100076
Revision: B.1
Plant: PLT01
Station: ST-61
Torque (Nm): 2.5
Cycle time (s): 198

Step 1: Record result

Step 2: Record result

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Visual check

Step 6: Record result

Assembly of P-100078 at plant PLT04

Part Number: P-100078
Revision: A.1
Plant: PLT04
Station: ST-14
Torque (Nm): 5
Cycle time (s): 162

Step 1: Visual check

Step 2: Record result

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Inspect incoming part

Step 7: Apply thread locker

Step 8: Apply thread locker