WORK INSTRUCTION

Document ID: DOC-0001852
Project: PRJ-003
Uploaded on: 2025-04-01
Uploaded by: user056
Export class: EAR99

Assembly of P-102589 at plant PLT04

Part Number: P-102589
Revision: A.1
Plant: PLT04
Station: ST-57
Torque (Nm): 8
Cycle time (s): 82

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Record result

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Move to next station

Assembly of P-101904 at plant PLT01

Part Number: P-101904
Revision: A.1
Plant: PLT01
Station: ST-63
Torque (Nm): 12
Cycle time (s): 32

Step 1: Visual check

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Clean mating surface

Step 8: Fit fasteners