WORK INSTRUCTION

Document ID: DOC-0001866
Project: PRJ-024
Uploaded on: 2025-04-15
Uploaded by: user104
Export class: EAR99

Assembly of P-101180 at plant PLT03

Part Number: P-101180
Revision: A.1
Plant: PLT03
Station: ST-96
Torque (Nm): 12
Cycle time (s): 243

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Fit fasteners

Assembly of P-100582 at plant PLT01

Part Number: P-100582
Revision: B.1
Plant: PLT01
Station: ST-73
Torque (Nm): 8
Cycle time (s): 100

Step 1: Torque to specification

Step 2: Visual check

Step 3: Record result

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Record result