WORK INSTRUCTION

Document ID: DOC-0001883
Project: PRJ-028
Uploaded on: 2025-04-25
Uploaded by: user115
Export class: EAR99

Assembly of P-102139 at plant PLT02

Part Number: P-102139
Revision: B.1
Plant: PLT02
Station: ST-19
Torque (Nm): 8
Cycle time (s): 257

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Torque to specification

Step 4: Record result

Step 5: Visual check

Step 6: Apply thread locker

Step 7: Move to next station

Step 8: Fit fasteners

Assembly of P-102981 at plant PLT03

Part Number: P-102981
Revision: A.1
Plant: PLT03
Station: ST-26
Torque (Nm): 8
Cycle time (s): 291

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Torque to specification