WORK INSTRUCTION

Document ID: DOC-0001930
Project: PRJ-032
Uploaded on: 2025-05-14
Uploaded by: user001
Export class: EAR99

Assembly of P-101040 at plant PLT02

Part Number: P-101040
Revision: A.1
Plant: PLT02
Station: ST-69
Torque (Nm): 20
Cycle time (s): 281

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Torque to specification

Step 4: Move to next station

Step 5: Inspect incoming part

Step 6: Clean mating surface

Step 7: Clean mating surface