WORK INSTRUCTION

Document ID: DOC-0001939
Project: PRJ-027
Uploaded on: 2025-05-17
Uploaded by: user030
Export class: EAR99

Assembly of P-102689 at plant PLT02

Part Number: P-102689
Revision: A.1
Plant: PLT02
Station: ST-48
Torque (Nm): 5
Cycle time (s): 68

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Move to next station

Step 6: Clean mating surface

Assembly of P-100565 at plant PLT03

Part Number: P-100565
Revision: A.1
Plant: PLT03
Station: ST-44
Torque (Nm): 12
Cycle time (s): 74

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Move to next station

Step 5: Fit fasteners

Assembly of P-102720 at plant PLT03

Part Number: P-102720
Revision: A.1
Plant: PLT03
Station: ST-38
Torque (Nm): 12
Cycle time (s): 214

Step 1: Torque to specification

Step 2: Torque to specification

Step 3: Visual check

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Move to next station

Step 8: Move to next station