# WORK INSTRUCTION

**Document ID:** DOC-0001970
**Project:** PRJ-040
**Uploaded on:** 2025-05-30
**Uploaded by:** user122
**Export class:** EAR99

## Assembly of P-100032 at plant PLT01

**Part Number:** P-100032
**Revision:** C.1
**Plant:** PLT01
**Station:** ST-62
**Torque (Nm):** 20
**Cycle time (s):** 265

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Fit fasteners

Step 7: Inspect incoming part